



ERGO L

Cooler Master Ergonomic Chair



Quantity: 1 pcs.
NW/GW: 27.8/33.4 Kgs.
CTN size: 67x54x74.5cm.



Asia Pacific - Cooler Master Technology Inc.
8F., No. 788-1, Zhongheng Rd., Zhonghe Dist., New Taipei City 23586, Taiwan (R.O.C.)
Tel: +886-2-2225-3517

China - Cooler Master China
7th Floor, Building C, Hongqiao R&F Center, No.7, 958 Lane, Shenhong Rd., Minhang District, Shanghai City 200051, China
Tel: +86-21-51872177

Europe - Cooler Master Europe B.V.
Lodewijkstraat 1b, 5652AC, Eindhoven, The Netherlands
Tel: +31-(0)40-702-0900


North America - Cooler Master NA
2929 E Imperial Highway, Ste110, Brea CA, 92821, USA
Tel: +1-888-624-5099
Cooler Master Support:
<https://account.coolermaster.com>

©2019 Cooler Master Technology Inc. All right Reserved. All trademarks are registered to their respective owners. Designed by Cooler Master. Made in China.

Cooler Master Website
For the most updated information, please visit our official website:
www.coolermaster.com




















Make It Yours.



ERGO L

Cooler Master Ergonomic Chair
Instruction Manual

ERGO L Cooler Master Ergonomic Chair Assembly Instruction

| | | | | |
|---|--|--|--|--|
| <p>A</p>  <p>Backrest x1</p> | <p>B</p>  <p>Seatbase x1</p> | <p>C</p>  <p>Armrest x2</p> | <p>Step 1</p>  | <p>Step 2</p>  |
| <p>D</p>  <p>Five Spokes Aluminum Base x1</p> | <p>E</p>  <p>Performance wheels x5</p> | <p>F</p>  <p>Gas lift x1</p> | <p>Step 3</p>  | <p>Step 4</p>  |
| <p>G</p>  <p>Headrest x1</p> | <p>H</p>  <p>Tool x1</p> | | <p>Step 5</p>  | <p>Complete</p>  |
| <p>I</p>  <p>Base screws x4</p> | <p>J</p>  <p>Armrest screws x6</p> | <p>K</p>  <p>Headrest screws x2</p> | | |